


3-4. LCD Module, Button (Control)

Note: On installation, adjust the position of both switch and knob (hold).



3-5. MAIN Board

