

(DISPLAY)

VIDEO/TV S005 VOL- S004 VOL+ S003 CH- S002 CH+ S001

[FUNC] [TV SYSTEM] [AUTO] [PRESET] [ANALOG -] [ANALOG +] S009 S008 S007 S006




C004 100 16V C005 0.1 PT R004 4.7K R005 4.7K

TO K BOARD
K-2

TO C BOARD
C-3


A-22

A-1




TO SC BC
SC-2


A-32




TO SC B
SC-1


A-31





A (SYS CONTROLLER, TU MEMORY, IF Y/C JUNGLE, H/V OUT) POWER SUPPLY





SONY
TRINITRON® CO
KV-2184 MT/RM

