


10.3 P.C.B SUB ASSY (AMP)

J P.C.B SUB ASSY (AMP) (7028067521010-IL)



- (FL) → : Audio Signal Route (Front L ch)
- (SL) → : Audio Signal Route (Surround L ch)
- (C) → : Audio Signal Route (Center ch)

