

.A503	Control module for cooling ventilator
.A509	Heat control module
.A510	Multi-function module
.B526	Electronic AC pressure sensor
.M500	Passenger compartment heater blower
.M513	Cooling ventilator right side
.R500	Blower fan resistor
.S510	Cabin ventilator switch
.S513	Switch for coolant inhibitor valve
.S514	Recirculation switch
.S515	A/C connector
.S518	Temperature switch for evaporator
.S519	Defroster switch
.S527	Electric rear window switch
.Y500	Solenoid clutch
.Y501	Solenoid valve for recirculation shutter
.Y502	Solenoid valve for coolant inhibitor valve
A20	Tachometer
A24	Instrument cluster
A42	Engine temperature indicator
A54	ECU
B22	Coolant temperature sensor
F -	Fuse by battery
M18	Cooling fan
S30	Heated rear window
X11	Diagnostic connector
X32	Collector plug