


**NAVODILO ZA UPORABO
UPUTSTVO ZA RUKOVANJE
INSTRUCTION MANUAL**

**RLC - MOST
MA 4301**


Izdanje 1971/2




**ELEKTROMEHANIKA — TELEKOMUNIKACIJE
— ELEKTRONIKA — AVTOMATIKA — ELEMENTI**



MA 4301 – Merni mostovi kod raznih merenja




MA 4301 - Strafnja ploča
 MA 4301 - Čeona ploča



Levi bok

Desni bok

MA 4301 - Rasporod elementata



Svi otpornici su $\pm 0.5\%$, osim ako nisu drukcije označeni

Svi kondenzatori su $\pm 10\%$ 490V, osim ako nisu drukcije označeni

0.5 W

* baždari se



MA 4301 – Električna shema