

# Panasonic

Digital Cordless Phone

Model No. **KX-TG7200E/KX-TG7202E**  
**KX-TG7203E**


Digital Cordless Answering System

Model No. **KX-TG7220E/KX-TG7222E**  
**KX-TG7223E/KX-TG7224E**

## Quick Guide

### Connections


#### Base unit



#### Important:

- If you use a telephone line cord which is not supplied, the unit may not work properly.

#### Charger (KX-TG7202/KX-TG7203/KX-TG7222/KX-TG7223/KX-TG7224)



### Battery installation/Battery charge

**Initial charge: 7 hours**

**Note:**

- USE ONLY rechargeable Ni-MH batteries.
- Do NOT use Alkaline/Manganese/Ni-Cd batteries.

\*1 The pictured model is KX-TG7200.  
\*2 KX-TG7202/KX-TG7203/KX-TG7222/  
KX-TG7223/KX-TG7224

### Operating tips

#### Using the navigator key

Press [▲], [▼], [◀], or [▶] to navigate through menus and to select items shown on the display.



#### Adjusting the receiver or speaker volume (🔊)

Press [▲] or [▼] while on a call.

### Date and time

- 1 [📄/OK]
- 2 Press [▲] or [▼] to select "Handset Setup". → [▶]
- 3 Proceed with the operation for your model.
  - KX-TG7200/KX-TG7202/KX-TG7203  
Press [▲] or [▼] to select "Set Date & Time". → [▶]
  - KX-TG7220/KX-TG7222/KX-TG7223/KX-TG7224  
Press [▲] or [▼] to select "Time Settings". → [▶] → Press [▲] or [▼] to select "Set Date & Time". → [▶]
- 4 Enter the current date, month, and year.
- 5 Enter the current hour and minute.
- 6 [📄/OK] → [🔒]

<b>Basic operations</b>	
<b>☎ Making/Answering calls (Handset)</b>	
Making calls	Dial the phone number. → [☎]/[☎]
Answering calls	[☎]/[☎]
Hanging up	[✕⓪]
Receiver/speaker volume	Press [▲] or [▼] while on a call.
Making a call using the redial list	[☎] → [▲]/[▼]: Select the desired number. → [☎]
Handset ringer volume	<ol style="list-style-type: none"> <li>1 [☐/OK]</li> <li>2 [▲]/[▼]: "Handset Setup" → [▶]</li> <li>3 [▲]/[▼]: "Ringer Setup" → [▶]</li> <li>4 [▲]/[▼]: "Ringer Volume" → [▶]</li> <li>5 [▲]/[▼]: Select the desired volume. → [▶] → [✕⓪]</li> </ol>
<b>☑ Phonebook (Handset)</b>	
Adding entries (names and phone numbers)	<ol style="list-style-type: none"> <li>1 [☐] → [☐/OK]</li> <li>2 [▲]/[▼]: "New Entry" → [▶]</li> <li>3 Enter the party's name (16 characters max.). → [☐/OK]</li> <li>4 Enter the party's phone number (24 digits max.). → [☐/OK]</li> <li>5 [▲]/[▼]: "Save" → [▶] → [✕⓪]</li> </ol> <ul style="list-style-type: none"> <li>• To enter a name, see the character table in the operating instructions.</li> </ul>
Making calls	<ol style="list-style-type: none"> <li>1 [☐]</li> <li>2 [▲]/[▼]: Select the desired entry. → [☎]</li> </ol>
<b>☎ Answering system (Base unit): KX-TG7220/KX-TG7222/KX-TG7223/KX-TG7224</b>	
Answering on/off	Press [☎] to turn on/off the answering system.
Listening to messages	[▶]


Frequently asked questions	
Question	Cause & solution
Why is $\nabla$ flashing?	<ul style="list-style-type: none"> <li>• The handset is too far from the base unit. Move closer.</li> <li>• The base unit AC adaptor is not connected. Check the connections.</li> <li>• You are using the handset or base unit in an area with high electrical interference. Place the handset and base unit away from interference sources, such as antennas and mobile phones.</li> <li>• The handset is not registered to the base unit. Register it (page 6).</li> </ul>
What should I do when the handset does not turn on?	<ul style="list-style-type: none"> <li>• Make sure that the batteries are installed correctly.</li> <li>• Fully charge the batteries.</li> <li>• Clean the charge contacts and charge again.</li> </ul>
How long is the battery operating time?	<ul style="list-style-type: none"> <li>• When you are using fully-charged Ni-MH batteries (supplied batteries); In continuous use: 17 hours max. In continuous standby mode: 180 hours max.</li> <li>• It is normal for batteries not to reach full capacity at the initial charge. Maximum battery performance is reached after a few complete cycles of charge/discharge (use).</li> <li>• Actual battery performance depends on a combination of how often the handset is in use and how often it is not in use (standby).</li> </ul>
Can I keep the handset on the base unit or charger when I am not using it?	<ul style="list-style-type: none"> <li>• Even after the handset is fully charged, the handset can be left on the base unit or charger without any ill effect on the batteries.</li> </ul>
When should I replace the batteries?	<ul style="list-style-type: none"> <li>• If the batteries are fully charged until  is displayed, but  is displayed after a few calls, replace the batteries with new ones.</li> </ul>
What is a PIN?	<ul style="list-style-type: none"> <li>• The PIN is a 4-digit number that must be entered in order to change certain base unit settings. The default PIN is "0000".</li> </ul>
What do I need to do to display caller information?	<ul style="list-style-type: none"> <li>• You need to subscribe to Caller ID service. Consult your service provider/telephone company for details.</li> <li>• The message "You must first subscribe to Caller ID." will be displayed until you receive caller information after subscribing to Caller ID service.</li> </ul>

<b>Frequently asked questions</b>	
<p>What should I do when:</p> <ul style="list-style-type: none"> <li>- I hear static or sound cuts in and out?</li> <li>- there is interference from other electrical units?</li> </ul>	<ul style="list-style-type: none"> <li>● Place the handset and the base unit away from other electrical appliances.</li> <li>● Move closer to the base unit.</li> <li>● Your unit is connected to a telephone line with DSL service. We recommend connecting a filter (contact your DSL service provider) to the telephone line between the base unit and the telephone line jack.</li> </ul>
<p>What should I do when the operating time seems to be short even after I fully charged the batteries?</p>	<ul style="list-style-type: none"> <li>● Wipe the battery ends (⊕, ⊖) and the unit contacts with a dry cloth.</li> </ul>
<p>What do I need to do to erase the missed call number (for example, "3 calls") from the display?</p>	<ul style="list-style-type: none"> <li>● There are unviewed missed calls remaining. View them using the following method.</li> </ul> <ol style="list-style-type: none"> <li><b>1</b> [≡/OK]</li> <li><b>2</b> [▲]/[▼]: "Caller List" → [▶]</li> <li><b>3</b> Press [▼] to search from the most recent call, or press [▲] to search from the oldest call.</li> </ol>


## Registering a handset to the base unit

The supplied handset and base unit are pre-registered. When you purchase an additional handset, refer to the additional handset's installation manual for registration. If for some reason the handset is not registered to the base unit, register the handset.


- 1 [OK]
- 2 [▲]/[▼]: "Handset Setup" → [▶]
- 3 [▲]/[▼]: "Registration" → [▶]
- 4 [▲]/[▼]: "Register H.set" → [▶]



- 5 Proceed with the operation for your model.
  - KX-TG7200/KX-TG7202/KX-TG7203  
Press and hold [M] on the base unit for about 5 seconds. (No registration tone)



- KX-TG7220/KX-TG7222/KX-TG7223/  
KX-TG7224  
Press and hold [M] on the base unit for about 5 seconds, until the registration tone sounds.



- 6 Wait until "Enter Base PIN" is displayed.
  - Enter the base unit PIN (default: "0000").
  - [OK]



### Optional service (Caller ID)

If you subscribe to Caller ID service, you can:



– display caller information

### Sales and support information

#### Customer Care Centre

- For customers within the UK: 0844 844 3898
- For customers within the Republic of Ireland: 01289 8333
- Visit our website for product information: [www.panasonic.co.uk](http://www.panasonic.co.uk)
- E-mail: [customer.care@panasonic.co.uk](mailto:customer.care@panasonic.co.uk)

#### Direct Sales at Panasonic UK

- Order accessory and consumable items for your product with ease and confidence by phoning our Customer Care Centre Monday - Thursday 9:00am - 5:30pm, Friday 9:30am - 5:30pm (Excluding public holidays).
- Or go on line through our Internet Accessory ordering application at [www.panasonic.co.uk](http://www.panasonic.co.uk)
- Most major credit and debit cards accepted.
- All enquiries transactions and distribution facilities are provided directly by Panasonic UK Ltd.
- It couldn't be simpler!
- Also available through our Internet is direct shopping for a wide range of finished products, take a browse on our website for further details.

**Customer Care Helpline Tel. No.: U.K. 0844 844 3898 / R.O.I. 01289 8333**

# **IMPORTANT**

**If you have problems setting up  
or operating this product please  
call the Panasonic DECT Helpline**

**0844 844 3898 (UK)**

**01289 8333 (Repl of Ireland)**